

Jockimo™

Advanced Architectural Products

MirrorUnique™ installation guidelines

Jockimo hand silvered MirrorUnique™ glass is suitable for vertical applications in dry areas. It is not suitable for wet applications such as showers or tub surrounds.

SUITABLE SUBSTRATES:

- Tile Backer Board - (Primed)
- Un-painted Gypsum Wallboard - (Primed)
- Un-finished Wood - (Primed)
- Particle Board - (Primed)
- Concrete

SUBSTRATE PREPARATION

All walls should be plumb, square and free of movement.

Surface to be tiled must be clean, dry and free of dust, dirt, greasy film, paint or primer. All porous surfaces must be sealed with

Gunther Prime n' Seal (tile backer board, unpainted wallboard, wood, particle board, concrete, etc).

SETTING ADHESIVE

Mirror should be installed with CRL Gunther Extra/Build Mirror Mastic or equivalent. Do not use solvent glues, generic adhesives or construction adhesives (do NOT use Liquid Nails). It is highly recommended that you familiarize yourself with the application of mirror mastic prior to beginning installation.

CUTTING JOCKIMO MIRROR

Cuts required to complete the installation may be achieved by using a score and snap tile cutter with an appropriate wheel. You may also use a glass cutter and straight edge to score and snap the tile. HAND SILVERED GLASS IS DELICATE. IF FINISH PEELING AT EDGES OCCURS TAKE CARE WHEN CUTTING NOT TO PULL THE CUT PIECES AWAY FROM ONE ANOTHER. SCORE THE GLASS, SNAP THE GLASS DOWNWARD THEN UPWARD TO CUT BOTH GLASS AND SILVER LAYERS.

TOUCH UPS

Use Rustoleum Black Specialty Appliance Epoxy for any necessary touchup of the backing.

INSTALLATION OF JOCKIMO MIRROR

Apply 1" patties to the back of tile and firmly place onto substrate. Allow for 1/16" or larger joint between tiles. RECOMMENDED: CRL MIRROR MASTIC OR GUNTHER MIRROR MASTIC.